

WANT
TO KNOW
MORE?

zolyd.eu

STATEMENT OF COMPLIANCE WITH EUROPEAN UNION DIRECTIVES

Zolyd declares that this product is in compliance with the essential requirements and other relevant provisions from the following Directives: 2014/30/EU; 2011/65/EU, as applicable. The technical documentation required by the Conformity Evaluation Process is in Zolyd's possession and can be requested through support@zolyd.eu.

DISPOSAL OF BATTERIES AND ELECTRICAL OR ELECTRONIC EQUIPMENT WASTE

The existence of this symbol on the product, batteries or respective packaging, signifies that this product and the contained batteries can not be disposed as domestic waste. It is the user's responsibility to deliver this product at a batteries, electrical or electronic recycling pick-up point. The pick-up and separate recycling contributes for the preservation of natural resources and supresses potential negative consequences for the human health and the environment resultant of inadequate disposal of dangerous substances contained in batteries and electrical or electronic equipment. For additional informations regarding batteries, electrical or electronic recycling pick-up points, please contact your local municipal services.

TECHNICAL ASSISTANCE

Regarding technical issues, please visit www.zolyd.eu or contact us through support@zolyd.eu.

SAFETY - EU 2023/988

Electrical installation: Use only with certified and compatible computer power supply units. Do not connect or disconnect fans while the equipment is powered on.

Risk of electric shock: Never expose the PC case or fans to liquids. Do not use the product if cables or connectors are damaged.

Ventilation and heating: Ensure proper airflow when installing the PC case. Do not block the ventilation openings. Avoid placing the product near heat sources or in excessively humid environments.

Mechanical safety: Be careful when handling internal metal edges — risk of cuts. Keep fingers, hair, and objects away from operating fans.

Use and maintenance: This product is intended for indoor use only. Clean dust regularly with a dry cloth; never use solvents or aggressive cleaning products. Do not attempt to modify or repair fans without qualified technical assistance.

Intended users: Not suitable for children. Keep small parts (screws, accessories) out of the reach of children and pets.

ARGB FAN HUB INSTALLATION

The ARGB fan hub is located behind the motherboard's installation panel.

- 1) Turn off the PC and the PSU.
- 2) Plug the motherboard's RGB cable **(A)**; plug the SATA's power cable **(B)**; plug the RGB FX button's cable **(C)**.

- 3) Connect the fan LED plug **(D)** on LED 1 port and the fan power plug **(E)** on FAN 1 port.

Repeat step 3, correspondingly, for the other fans.

The LED and FAN port pins are fragile. Be careful, make sure they are properly aligned with the plugs during installation. Do not force.

COMPATIBILITY

Motherboard: Micro-ATX, Mini-ITX

CPU cooler: 155 mm max. height



GPU: 420 mm max. length

Connections: 2x USB-A 3.0; 1x USB-C 3.1; 1x audio in/out

Expansion slots: 5

Liquid cooling (not included):

Motherboard: 120 / 240 mm • Rear: 120 mm • Top: 120 / 240 / 360 mm



ACCESSORIES



x21 MB screws



x12 storage unit screws



x6 PSU screws



x3 MB spacers




x1 spacer key



x5 cable ties

OPENING THE PC CASE




Remove the screws located at the back of the left panel. Slide the panel backwards to release it.

Remove the screws located at the back of the right panel. Slide the panel backwards to release it.


STORAGE UNITS INSTALLATION

2x 3.5" STORAGE UNITS




1.1) Remove the storage units drawer from the PC case. Remove the screws and pull it out.

1.2) Place the 3.5" units inside the storage drawer. Attach the storage units to the drawer by inserting the screws through the top and bottom. Reinstall the drawer back into the PC case.




STORAGE UNITS INSTALLATION

3x 2.5" STORAGE UNITS




1.1) Remove the storage units drawer from the PC case. Remove the screws and pull it out.

1.2) Place the 2.5" units over the storage drawer. Attach the storage units to the drawer by inserting the screws through the inside. Reinstall the drawer back into the PC case.




EXTRA FANS OR LIQUID COOLING INSTALLATION


Align the fans or radiators with the fixation holes on the top, base and rear panels or Motherboard area on the PC case. Attach the fixation screws on the fans or radiators.




Top panel: 3x 120 mm or 2x 140 mm fans. 120, 240 or 360 mm radiators.



Motherboard: 2x 120 mm or 2x 140 mm fans. 120 or 240 radiators.



Rear panel: 1x 120 mm fan. 120 mm radiator.



Base: 3x 120 mm or 2x 140 mm fans.